Site	Water level or flow	Field Measurements	Laboratory Analysis	NPDES List
PRS-1	S	S	A	
PRS-1a**	Q	Q	Q	
PRS-4 (aka NE080)	S	S	А	
PRS-4a**	Q (then S)	Q (then S)	Q (then A)	
TH-201	Q			
TH-202	Q			
TH-203	Q			
PAW-1	S	S	S	
PAW1a**	Q (then S)	Q (then S)	Q (then A)	
PAW-2	S	S	А	
PAW-8	S	S	A	
PAW-9	S	S	S	
ACAW-1	S	S	S	
CCAW-1	S	S	S	
NEW-2	S	A	А	
NEW-3	S			
NEW-4	S	A	А	
NE-1-10	S	A	А	
NE-6-10a*	Q	Q	Q	
NE-6-10b*	Q	Q	Q	
NM-20*	Q	Q	Q	
NM-21*	Q	Q	Q	
NM-22*	Q	Q	Q	
NM-23*	Q	Q	Q	
SF-2*	Q	Q	Q	
NPDES Stations				
NE 001				+
(mine water pond)				
NE 004(Pond 4)				+
NE-007 (Pond 7)				+
NE 008 (Pond 8)				+
NE 080 (PRS-4)				+
KEY S=Semi-annually (2)	nd and 4th quarters) Q	=Quarterly A=Annu	ally (4th quarter)	

\*\* Monitor quarterly for one year, then frequency will change as indicated in table

+see NPDES permit for frequency and required analysis

Note: If the coal shipping facilities become active, the Division will be notified in writing and the frequency of monitoring reviewed and increased, if operational parameters warrant.